



# **STONE** Accessories

[www.stone4x4accessories.com](http://www.stone4x4accessories.com)

## **Fitting Instructions for Bonnet Top Chequer Plate**

**Product Code CP44**

- 1. Place bonnet chequer plate onto bonnet and adjust as needed.**
- 2. Mark holes and drill.**
- 3. Remove bonnet chequer plate and clean all drill filings.**
- 4. Re-apply bonnet chequer plate and rivet.**

**Contents: Bonnet chequer plate / x26 rivets.**

**Tools Required: #4.2mm drill / rivet gun.**

[www.stone4x4accessories.com](http://www.stone4x4accessories.com)