



STONE Accessories

www.stone4x4accessories.com

Fitting Instructions for Fender Tops

Product Code CP30

- 1. Place fender top chequer plate onto fender and adjust as needed.**
- 2. Mark holes and drill.**
- 3. Remove chequer plate and clean all drill filings.**
- 4. Reinstall chequer plate and rivet to fender (rivets supplied).**

Contents: x2 fender top chequer plate / x28 rivets.

Tools Required: #4.2mm drill / rivet gun.

www.stone4x4accessories.com